

# How to Install Your New...

## C & C2 LASHER GUARD

P/N 70011

### About Your Guard

This Lasher Guard is designed to protect your C/C2 Lasher from tree foliage and branches which otherwise might interfere with or damage your lasher.

The circular aluminum tube body has a hinged gate that opens to let the cable and strand pass through, then closes to provide 360° protection.

### Assembly Procedure

Locate the position of the two mounting holes. These two holes match the two pre-drilled holes on your lasher on either side of the cable opening, below the lip of the gear housing.

Place the guard with the **gate opening to the left** and against the front end of your C/C2 Lasher's front plate, making sure that both mounting holes in the guard line up with the pre-tapped holes on your lasher.

Insert the bolts through their mounting holes and tighten firmly, using a wrench, without over tightening.

For more information and assistance, contact our Technical Support Hotline: 1-800-345-6009

**Note:** C Lashers with serial numbers 87-5144 and earlier are not pre-drilled and pre-tapped. You'll need to get a C Template Kit (P/N 70013) in order to mount your C Lasher Guard. C2 Lashers are all pre-drilled and tapped



Ensure the gate opening is on the same side the front gate is mounted



Insert the bolts through their mounting holes and tighten firmly using a wrench. **Do not over tighten.**



### GENERAL MACHINE PRODUCTS (KT), LLC

3111 Old Lincoln Highway, Trevose, PA 19053

Tel: 215-357-5500 Fax: 215-357-6216

Email: [info@gmptools.com](mailto:info@gmptools.com) Web: [www.gmptools.com](http://www.gmptools.com)