



## E LASHING WIRE CLAMP INSTALLATION

1. Orient groove of clamp plate over strand as shown.
2. Cross lashing wire over top of strand 2 wraps **following the lay of the strand**. Thread it between stud collar and first washer. Then wrap 1/2 turn around stud. **Do not wrap lashing wire 360° around stud and avoid pinching lashing wire which may cause premature failure**
3. Tighten nut.
4. Tuck free end of lashing wire into clamp to prevent injury
5. If over-lashing, repeat steps 2 and 3 except place second lashing wire between two flat washers

## Caution

Failure to terminate lashing wire properly **will** result in premature failure.